



Note: User seal checks are not substitutes for qualitative or quantitative fit tests.

Positive Pressure Check

Close off the exhalation valve and exhale gently into the facepiece. The face fit is considered satisfactory if a slight positive pressure can be built up inside the facepiece without any evidence of outward leakage of air at the seal. For most respirators this method of leak testing requires the wearer to first remove the exhalation valve cover before closing off the exhalation valve and then carefully replacing it after the test.

For N-95 respirators without an exhalation valve, place hands around the exterior of the mask along the seal and exhale gently to check for leaks.

Negative Pressure Check

Close off the inlet opening of the canister or cartridge(s) by covering with the palm of the hand(s) or by replacing the filter seal(s), inhale gently so that the facepiece collapses slightly, and hold your breath for ten seconds. The design of the inlet opening of some cartridges cannot be effectively covered with the palm of the hand. The test can be performed by covering the inlet opening of the cartridge with a thin latex or nitrile glove. If the facepiece remains in its slightly collapsed condition and no inward leakage of air is detected, the tightness of the respirator is considered satisfactory.

For N-95 respirators with an exhalation valve, place hands around the exterior of the mask along the seal and exhale vigorously.