



PLAN NOTES

- ① INSTALL 3/4" BLOW OFF VALVE ON STRAINER WITH NIPPLE AND CAP.

A STEAM TRAP DETAIL
NO SCALE

