

Building: _____

Room: _____

EYEWASH FLUSH LOG

Turn on your emergency eyewash *at least* once a month for a minimum of 3 minutes and document in the log

Purpose of testing: Confirm the eyewash works correctly, flush sediment from the supply line, and reduce microbial growth from standing water



PASS criteria (after 3 minutes of operation)

- Water flow alone opens the covers without user assistance
- Water is clear and not too hot or cold
- Water reaches both eyes at the same time
- Streams of water maintain controlled flow and do not hurt the eyes



FAIL if any pass criteria is not met or you have other concerns about the station functionality

If FAIL: Email pme-facilities@uchicago.edu

- Include the room number
- Describe the eyewash location
(*Example: across from bench #3.*)
- Describe what is not working

Hyde Park Labs: Place a ticket to PME Facilities on FreshService or by emailing pme-facilities@uchicago.edu



PLEASE EMAIL RESEARCHSAFETY@UCHICAGO.EDU FOR ANY ADDITIONAL CONCERNS

[illegible][illegible][illegible][illegible]